

## DONNING INSTRUCTIONS



1. Lift yellow clip



2. Remove lid



3. Remove set from case by pulling firmly on base of the breathing hose



4. Remove set from case



5. Bungs detach and start-up of initial oxygen generator



6. Put strap around your neck



7. Insert mouthpiece and take a breath



8. Adjust the neck strap, fit nose clip and exhale into the mouthpiece



9. If needed, don the face shield and pull the yellow loops to tighten around the neck



10. Make a safe escape

**NOTE:**

The action of removing the breathing device from the case automatically activates the oxygen generation. The red sealing bung and cap are connected inside the case via a black lanyard. If, for any reason the bungs stay attached to the device when it has been removed, they should be removed manually before continuing to don the set.

Once donned, try to remain calm and maintain a steady work rate to ensure regular breathing. Rapid breathing uses more oxygen.

During use the starter and oxygen generator will increase in temperature. The oxygen provided will be warm and dry and you may detect slight odours or tastes. These are normal conditions and indicate the device is functioning correctly.

